

Photo	ハブモデル名	互換するカセットボディ		
		Shimano 9-10S	Shimano 9-11S	Campy 10-11S
	TK92839	TK271	設定なし	TK270
	TK191	TK273	設定なし	TK272
	TK1920	TK2752	設定なし	TK2742
画像なし	TK1921	TK2751	設定なし	TK2741
	TK195	TK275	設定なし	TK274
	TK197	TK2751 TK2751TBT	設定なし	TK2741 TK2741TBT
	TK520	TK2752 TK2752TBT	設定なし	TK2742 TK2742TBT
	ARSENAL TK198	TK2752 TK2752TBT	設定なし	TK2742 TK2742TBT
	ARSENAL Q TK1971	TK2754 TK2754TBT TK2754TFT		TK2742 TK2742TBT TK2742TFT
	ARSENAL Q PRO TK5201	TK2754 TK2754TBT TK2754TFT		TK2742 TK2742TBT TK2742TFT
	ARSENAL TK1981	TK2754 TK2754TBT TK2754TFT		TK2742 TK2742TBT TK2742TFT
	HERO TK199	TK2754 TK2754TBT TK2754TFT		TK2742 TK2742TBT TK2742TFT
	TK1962	TK277		TK278
	MARU0708	MARU0708 or TK277		MARU0709 or TK278
	TK1963	TK2772		TK2782

Photo	ハブモデル名	互換するカセットボディ	
		SHIMANO 9-11S / SRAM 9-10S	SRAM 11S
画像なし	TK4901	TK2715	設定なし
画像なし	TK4902	TK2716	設定なし
	TK4913	TK2752	TK2742
	TK49135	TK2752	TK2742
	TK4915	TK2712	設定なし
	TK4923	TK2752	TK2713X
	TK4925	TK2752	TK2713X
	TK4936	TK2755	TK2714X
	TK4925/2	TK2717A	TK1718X
	TK4936/2	TK2717	TK2718X
画像なし	TK495	TK2754	TK2742